

PRODUCT NAME

Albi Cote IB is an ignition barrier coating supplied by:

Albi Protective Coatings
401 Berlin Street
East Berlin, CT 06023

PRODUCT DESCRIPTION

Albi Cote IB is a proprietary, water based, 1-part, non-flammable, intumescent coating complying with AC 377 ICC ES for interior use. This coating expands up to 2000% and provides oxygen starvation when in contact with fire. This barrier coating / ignition barrier comes in both insulating and fire extinguishing versions and is a non-toxic, drain safe, no fuming, water-based coating.

Albi Cote IB has low-viscosity for ease of application.

Applications for Albi Cote IB include:

- Walls, Attics, Crawl Spaces
- Open cell SPF insulation
- Closed cell SPF insulation

Albi Cote IB passes NFPA complying with AC 377 ICC ES Appendix X over many SPF insulation systems and carries the following building code, industry, and environmental approvals:

- E84 Class 'A' rated
- LEED Certified Green Product
- Meets EPA Low-VOC Standard

APPLICATION PROCEDURES

Albi Cote IB should be installed only after SPF core temperature has assumed ambient temperature for 2 hours.

The successful installation and effectiveness of IB will depend on many factors including the equipment capabilities & settings, the temperature of the coating in the container, ambient temperature & RH%, substrate temperature & moisture content, substrate type & condition. It is the responsibility of the applicator to take these factors into consideration prior to installation.

Cold material will develop higher viscosity which can cause problems during processing such as pump cavitation and poor pre-mixing material. If

LIQUID PROPERTIES & PHYSICAL CHARACTERISTICS

Property	Value	Test Method
Viscosity:	100-120 KU	ASTM D562
Solids % by Volume:	58% (+/- 3%)	ASTM D2697
Weight Per Gallon:	10.9 lbs. (+/- 0.3)	ASTM D1475
VOC:	<50 g/L	Method 24
Toxicity/Solvents:	Non-toxic, water-based	
Shelf Life:	1 year from date of manufacture if stored 45 -100 °F	
Colors:	Off-white	
Packaging	5-gal pail or 55-gal drum	
Storage Temperature Range (STR)	> 45 °F	

PROCESSING & EQUIPMENT PARAMETERS

Property	Value
Tack Free Time:	60 - 90 minutes @ 77 °F & 50% R.H.*
Full Cure Time:	3 weeks
Sag Resistance:	35 mils on walls; 20 mils on ceilings*
Processing Pressure:	>2200 PSI at the gun tip*
Minimum Material Temperature:	>62 °F
Ambient Temperature Range:	55 - 95 °F
Minimum Substrate Temperature:	> 55 °F
Ambient RH% Range:	40% – 60% (see ventilation procedures)
Recommended Sprayer:	Graco 695 or equivalent – 2200psi at tip w/ 3/8" line
Recommended Gun:	Graco HD Texture Gun (p/n 241705) or equivalent
Recommended Tip Size:	.517 - .521 reversible, self-cleaning is recommended
Coverage:	80 – 92 sq. ft. per gal.**

COMBUSTION PROPERTIES

Property	Value	Test Method
Flame Spread Index:	<25	ASTM E-84
Smoke Development:	<50	ASTM E-84

**Drying times and processing parameters can vary widely depending on substrate temperature, condition, ambient temperature, elevation, humidity, equipment and other factors. During installation, the applicator must observe the quality and characteristics of the coating and spray pattern and adjust equipment setup and/or settings as needed to ensure proper cure time, adhesion, coverage, and performance of the coating.*

*** Consult your Albi representative for required coverage rates for your specific application. Actual coverage rates may vary depending on the finished surface texture.*

material appears thickened due to storage at cold temperatures, store material in a warm area prior to application to bring material temperature to > 62° F.

Albi Cote IB is applied with airless spray equipment.

When using airless spray equipment ensure the equipment has a volume output not less than 0.74 gpm (gallons per minute) and an operating pressure of 3300 psi. The sprayer should be equipped with a

filter screen 30-mesh.

To ensure proper pressure and delivery to the spray gun use the following rules for hose diameter & length:

- Min. 3/8" ID up to 75'
- Min 1/2" ID up to 200'
- Min 3/4" ID greater than 200'
- Min 3/8" ID & Max 6' L for whip hose

Always use larger diameter hose sections nearest the pump.

We recommend using a Graco Reverse-A-Clean (RAC) X gun tip with no internal diffuser and an orifice size of .517 - .521.

ALWAYS USE EQUIPMENT AND COMPONENTS WITH THE PROPER PRESSURE AND MATERIAL DELIVERY RATINGS THAT ARE IN GOOD WORKING ORDER.

A natural bristle brush or a medium nap roller can be used for touch-up and edge work, or for small areas that are not practical for spray application.

Most SPF insulation systems can be coated in a single application to achieve building code compliance. Consult your Albi representative for recommended coverage rates for your specific SPF insulation product.

Should your SPF product require more than one coat to comply with building code, individual coats of Albi Cote IB should be applied in perpendicular direction to the previous coat to achieve a cross-hatching application.

The maximum single-pass application rate for Albi Cote IB is 12 wet mils.

The actual dry film thickness achieved in the field application is dependent upon many variables including method of application, and surface textures. It is the sole responsibility of the coating applicator to apply the proper amount of material required to achieve the minimum dry film thickness specified for the given requirements for the project.

To accurately achieve proper coverage applicator must check wet film thickness during application with a wet film gauge on multiple coupons evenly spaced throughout the project application area. Dry film thickness (DFT) is calculated from a measured wet film thickness (WFT) equation as follows:

- $DFT = WFT \times \% \text{ solids by volume}$

To calculate your Theoretical Application Rate (TAR) in gallons per 100 square feet, use the following equation:

- $TAR = (WFT)/16$

DO NOT APPLY WHEN SUBSTRATE SURFACE IS BELOW 55 °F, OR WHEN WEATHER CONDITIONS WILL NOT ALLOW ADEQUATE CURING OF THE COATING.

DO NOT APPLY IF RAIN, DEW, OR FREEZING TEMPERATURES ARE LIKELY TO OCCUR BEFORE PRODUCT CAN DRY AND CURE.

DO NOT APPLY WHEN AMBIENT TEMPERATURE IS WITHIN 5 °F OF THE DEW POINT OR IS EXPECTED TO BE WITHIN 5 °F OF THE DEWPOINT WITHIN 24 HOURS FOLLOWING APPLICATION.

STORAGE, MIXING & THINNING

Albi Cote IB is available in ready-to-use, factory-sealed, standard-sized, five-gallon pails or fifty-five-gallon drums. Other container sizes may be available upon request.

DO NOT ALLOW MATERIAL TO FREEZE.

Storage at temperatures below acceptable minimum storage temperature may shorten shelf life. Product warranty is void if material is stored below or above recommended storage temperature.

DO NOT THIN.

Prior to use thoroughly mix Albi Cote IB with an air or electrically driven power mixer for a minimum of 2-4 minutes or until product color and viscosity is uniform. Mixer speed should be set fast enough to uniformly mix the entire container but not so fast as to introduce air into the coating while mixing. For five-gallon pails use a minimum 3" mixing blade, for drums use a minimum 6" mixing blade.

Previously opened containers, or containers that have been stored for an extended length of time, may develop a skin on top of or at the edges of the coating, which must be removed prior to mixing.

SURFACE PREPARATION

SURFACE TEXTURE OF SPF WILL GREATLY AFFECT MATERIAL ADHESION, SAG RESISTANCE, AND COVERAGE RATE.

SPF surface should have a fine, orange-peel texture (or rougher), and be flat for optimum adhesion and material coverage. SPF surface that is bumpy, or significantly uneven will decrease coating coverage.

SPF that has a glossy or slick appearance may need to be abraded or "scuffed" to roughen the surface to promote adhesion of coating.

SPF surface must be clean, dry and free of any mildew, oil, grease, dirt, or other foreign contaminants that would prevent proper adhesion.

Any such contaminants must be removed from the application surface.

For application in high humidity or low temperature environments apply product in thin passes to promote proper drying & curing.

SAFETY & ENVIRONMENT

Albi Cote IB is installed by independent contractors. It is recommended that building owners verify that your contractor maintains proper credentials, insurance, licenses, and is properly trained to safely install coatings.

Albi Cote IB achieves a Class A Fire rating. It is formaldehyde-free, halogen-free, low-VOC, HFC-free, and PBDE-free.

Always read and follow all job site safety requirements as set forth by state and federal safety regulatory agencies such as OSHA and NIOSH.

Always read and follow all Material Safety Data Sheets provided with all shipments. Additional copies are available upon request from Albi or your technical representative.

Basic PPE safety equipment is required for personal protection including, but not limited to: long-sleeve chemically resistant overalls, rubber gloves, splash shield or safety glasses with splash guards, rubber or leather boots w/ covers.

DO NOT USE NEAR HIGH HEAT OR OPEN FLAME.

DO NOT TAKE INTERNALLY AND PREVENT CONTACT WITH SKIN OR EYES.

KEEP OUT OF THE REACH OF CHILDREN.

CURE TIME & RECOATING

The Albi Cote IB coating is latex based. To ensure that successive coats are applied properly, it is important to understand how they dry and cure. As the coating dries, the liquid components evaporate. As liquid evaporates from the coating it becomes cured while the evaporated liquid becomes water vapor suspended in the air surrounding the coating.

The drying time between coats is normally longer than simply "dry to touch" or "tack-free", especially with thicker coating applications. "Dry to touch" or "tack-free" means you can touch a coated surface without getting paint on your hand. While this is a stage in the curing process, this indicates that the

liquids have evaporated only from the surface of the paint, and does not mean that the coating is dry enough to add a second coat without creating significantly longer drying time.

Building a thick coating, intentionally or unintentionally, or spraying the coating over an uncured substrate may create problems in the drying and curing process. Until all the liquids have completed evaporated, the coating is not cured. Normal full cure time is 2-4 weeks. Once cured the coating becomes a durable and inert fire protective finish. Even under adverse application conditions, the coating will eventually cure; however, the noncompliant application procedure may affect adhesion quality, lingering odors, drying time, and the warranty of the coating.

ENVIRONMENTAL CONDITIONS & DRYING

Proper ambient air-movement, proper substrate and coating temperatures, and low humidity are necessary for proper adhesion and drying of the coating. The following example illustrates the drying potential of 10,000 ft.³ of air at various temperatures:

- 90 °F air can evaporate 2.6 gal of water
- 40 °F air can evaporate 0.5 gal of water

The Albi Cote IB coating is approximately 68% solids which mean each five-gallon pail of coating contains roughly 1.5 gallons of water that must be evaporated from for the coating to dry and cure.

As a reference, an attic in a 1,600 ft.² house with a gable roof that has an 8/12 pitch will have an attic volume of approximately 10,600 ft.³. Based on the above illustrations, conditions in this attic would need to be extremely dry with an interior temperature more than 90 °F prior to coating application to be assured of proper drying of one five-gallon pail of coating.

Low temperatures or humidity over 70% RH in the attic prior, during, or after application can hinder drying of the coating and can produce lingering odors due to the slow evaporation of the liquid components.

Odors emitted from the coating as it dries should be similar to those found in low-odor latex paint. Under proper drying conditions these odors should quickly dissipate and not cause any lingering issues.

To avoid problems associated with improper drying of the coating always observe Application Procedures and product recommendations.

VENTILATION

Closed areas, such as unvented attics, will require mechanical, negative-pressure, cross ventilation during the spraying and drying period. Mechanical, negative-pressure, cross ventilation is the ONLY effective method of ventilating closed or confined spaces where coatings must be applied to ensure proper drying.

For ventilation, it is important to ensure you create negative pressure (vacuum) in the enclosed spray area to evacuate water vapor and any off-gassed components of either the SPF insulation system or coating to exterior, unoccupied space. This can be achieved using a whole-house ventilation technique outlined below:

- Review and observe all application parameters, product limitations & recommendations on the technical data sheet to ensure the work environment is suitable for the application of coating.
- Inspect the foam substrate to ensure it is dry, clean and secured to its substrate.
- Use a "supply" blower to draft fresh exterior air to one end of the enclosed space via a hose from the non-occupied exterior.
- Ensure the supply air flows across the immediate vicinity of the spray operation.
- Use an "exhaust" blower to evacuate the stale, moisture laden air from the opposite end of the enclosed space through a hose to the exterior of the building.
- The exhaust blower must have a larger air volume output than the supply blower to ensure the enclosed space is maintained at a negative pressure in relationship to the surround area.
- Do not arrange the ends of the hoses where the supply air is drafting air from the exhaust hose.
- Do not exhaust the stale air into any living space or garage area. It must be exhausted to a safe uninhabited open area.
- Place a filter over the exhaust hose to avoid spreading overspray.
- Ensure the lengths of supply and exhaust hoses and filter do not restrict the air movement.
- Constant monitoring of humidity and temperature is necessary until coating has dried thoroughly to ensure the spray environment remains within the application parameters specified on the coating technical data sheet. If the humidity exceeds 70% RH during the drying period

while using mechanical, negative-pressure, cross-ventilation, then mechanical dehumidification may be required as supplementary drying aid until the coating is thoroughly dry.

DO NOT USE PROPANE, KEROSENE, OR DIESEL COMBUSTION HEATERS TO HEAT A CLOSED SPACE.

Burning fuels like this in a confined space depletes oxygen and can create a dangerous buildup of toxic gasses including CO and CO². Always observe OSHA and NIOSH regulations for using heaters in confined or closed spaces.

In addition, the process of burning fuels such as kerosene, propane, or diesel adds significant amounts of water vapor to the environment, which furthers hinders the evaporative drying process.

ADDITIONAL LIMITATIONS

Albi Cote IB should not be used for exterior applications.

It should not be used where it will stay submerged in water or below grade where back-fill material will be in permanent contact with the coating.

Albi Cote IB should not be used in areas that are or will be subjected to extreme temperature or humidity conditions such as swimming pool rooms, hot yoga studios, spas, hot tubs, saunas, cold-storage, or other areas where temperatures or humidity levels may be abnormally high or low under normal use. Contact your Albi representative if you have questions regarding other extreme use applications.

Installation must comply with all applicable building codes.

DISPOSAL & CLEAN UP

Consult Safety Data Sheets (SDS) prior to handling and disposal. Cured product may be disposed of without restriction. Product containers that are "drip free" may be disposed of according to local, state and federal laws. Spills or overspray during application can be cleaned/removed with soap and water for uncured material.

COLORS & FINISH

Albi Cote IB produces a flat finish when fully cured and comes in standard off-white.

All other colors are custom matched by Albi for the specific application. Contact Albi for all custom colors. Samples must be approved by customer prior to production.

Additional fees and minimum order quantities apply for all custom colors. Talk to your Albi representative for details.

DISCLAIMER

The information provide herein is believed to be reliable, but unknown risks may be present.

The data presented herein is subject to change without notice and is not intended for use by nonprofessional applicators, or those who do not purchase or utilize this product in the normal course of their business.

The contractor, building owner, and/or applicator are responsible to perform any pertinent tests to determine the product's suitability for the intended application.

The installer is responsible to adhere to all health and safety requirements including OSHA, NIOSH and any others that may have jurisdictional authority in the application area.

Final determination of fitness of the product for any particular use is the responsibility of the buyer.

USEFUL TOOLS AND INSTRUMENTS

Whole-house ventilation blower and hose assembly. These items are available at many industrial supply and safety stores and online including Northern Tool and Equipment, (www.northerntool.com)

Uninsulated, flexible HVAC duct may be used for ducting the air into and from the workspace as a convenient and inexpensive alternative to the hose assembly shown below



A hand-held temperature and moisture meter like the Fluke 971 shown below is an ideal instrument for monitoring the workspace environment to ensure

it is within acceptable spraying and application parameters. This instrument is available from several online sources.



If mechanical dehumidification is required to enable drying. A standard household or commercial dehumidifier like the Ebac RM85 shown below can be used until the coating is thoroughly dry. Typically, mechanical dehumidification will be required continuously for several days after coating application and units like the one below are often available for rent at an industrial rental store or can be purchased online.

